

Xtra Long Life 100 million cycles

USB/Ethernet RF Switch Matrix **RC-2SPDT-A18**

50Ω DC to 18 GHz

The Big Deal

- **USB or Ethernet-TCP/IP (HTTP and Telnet protocols) control**
- Capable of 100 million cycles
- 2 SPDT electromechanical, absorptive RF switches (85 dB typ. isolation)
- Programmable to different switch configurations
- Plug-and-Play usable with Windows®, Mac®, and Linux® computers



Case Style: LM1849



Installation CD



Product Overview

Mini-Circuits' RC-2SPDT-A18 is a general purpose RF switch matrix controlled via either USB or Ethernet-TCP/IP (supports HTTP and Telnet protocols). The model contains two electromechanical SPDT, absorptive fail-safe RF switch constructed in break-before-make configuration and powered by +24VDC with switching time of 25 ms typical. The two switches can be set as two independent SPDT switches, or a single DPDT or SP3T switch (see pages 6 – 10 for configuration details). The RF switches can be operated remotely using the supplied GUI software or programmed by the user with the included API objects. The RF switches operate over a wide frequency band from DC to 18 GHz, have low insertion loss (0.2 dB typical) and high isolation (85 dB typical) making the switch matrix perfectly suitable for a wide variety of RF applications.

The RC-2SPDT-A18 is constructed in a compact, rugged metal case (4.5" x 6.0" x 2.25") with 6 SMA(F) connectors (COM, 1, and 2) for each switch, a 2.1mm DC socket, USB type B port, and a standard RJ45 network socket. The model is supplied with our easy-to-install, easy-to-use GUI software and API objects for Windows environments with complete programming instructions for 32 and 64 bit Windows® and Linux® operating systems. Also included is a 2.7 ft. USB cable, a 5 ft. Ethernet cable for Ethernet (HTTP and Telnet) control, and a power adaptor suitable for US, EU, and other power systems. See page 12 for list of all accessories included. Longer USB cables and a mounting bracket are available as additional accessories.

Key Features

Feature	Advantages
Ethernet-TCP/IP- HTTP and Telnet Protocols (Supports DHCP and Static IP)	The RC-2SPDT-A18 switch matrix can be controlled from any Windows®, Mac®, or Linux® computer, or even a mobile device with a network connection and Ethernet-TCP/IP (HTTP or Telnet protocols) support. Using a VPN would allow remote control from anywhere in the world.
USB HID (Human Interface Device)	User may also control the switch matrix via USB connection. Plug-and-Play, no driver required. Compatible with Windows® or Linux® operating systems using 32 and 64 bit architecture.
RF SPDT absorptive electromechanical switches	Wideband (DC to 18 GHz) with low insertion loss (0.2 dB typ.), very high isolation (85 dB typ.), and high power rating (10W cold switching).
24VDC operating voltage	The RC-2SPDT-A18 requires 24V / 610mA to power the RF switch, supplied from the power adaptor (included).
GUI Software CD, programming instructions, USB & Ethernet cables, and 24VDC power adaptor included	The RC-2SPDT-A18 comes ready to use out of the box with all software, accessories, and instructions needed for immediate operation included.

Xtra Long Life 100 million cycles

USB/Ethernet RF Switch Matrix

RC-2SPDT-A18

50Ω DC to 18 GHz

Features

- Capable of 100 million cycles
- Two DC to 18 GHz SPDT absorptive fail-safe RF switches in break-before-make configuration
- Electromechanical switching (Isolation 85 dB typ.)
- High power handling, 10W
- Greatly simplifies complex switching and timing setups
- USB HID or Ethernet-TCP/IP **HTTP** and **Telnet** control
- Easy installation and operation
- Supports a wide range of programming environments (See [AN-49-001](#) for details)¹
- Mounting bracket (Optional)
- Protected by US Patents 5,272,458; 6,414,577; 6,650,210; 7,633,361 and 7,843,289



Case Style: LM1849

Installation CD

Model No.	Description	Price	Qty.
RC-2SPDT-A18	USB/Ethernet RF Switch	\$785.00 ea.	(1-9)
Included Accessories			
AC/DC-24-3W1	AC/DC 24V Adapter (see <i>Ordering Information</i>)	1	
CBL-3W1-XX	AC Power Cord (see <i>Ordering Information</i>)	1	
USB-CBL-AB-3+	2.7 ft USB cable	1	
CBL-RJ45-MM-5+	5 ft. Ethernet cable	1	
RFSW-CD	Installation CD	1	


RoHS Compliant

See our web site for RoHS Compliance methodologies and qualifications

Applications

- R&D
- Automated Test equipment
- Controlling RF signal paths

Mini-Circuits RF Switch Control Program for **USB/Ethernet** RF Switch Matrix



Steps to start RC-2SPDT-A18 GUI via USB

- Click on USB button.
- If more than one unit is connected select S/N from list and click OK.
- Start working.

- For Demo mode of any Switch Matrix model select the model name from the drop box and click 'Start Demo' (See [user guide](#) for details)
- For programming instructions of the switch matrix see [programming guide](#) and [AN-49-001](#) on Mini-Circuits' website

Steps to start RC-2SPDT-A18 GUI via Ethernet

- Click on search icon.
- Select unit from list of IP addresses and click select
- The selected IP will appear in the IP Address field.
- Select communication protocol (Telnet or HTTP)
- Click on Start and begin working.

¹ Windows is a registered trademark of Microsoft Corporation in the United States and other countries. Linux is a registered trademark of Linus Torvalds. Mac is a registered trademark of Apple Corporation in the United States and other countries.

Neither Mini-Circuits nor the Mini-Circuits RC-2SPDT-A18 are affiliated with or endorsed by the owners of the above referenced trademarks.

Mini-Circuits and the Mini-Circuits logo are registered trademarks of Scientific Components Corporation.

Electrical Specifications

Parameter	Port	Conditions	Min.	Typ.	Max.	Units
Rated Voltage	24V _{DC} IN USB Port	provided via external power adapter -	23 -	24 5	25 -	V
Power On Sequence: Connect the 24V power, followed by the USB control and/or Ethernet cable before turning on the Switch Matrix.						
Rated Current	24V _{DC} IN	All switches in COM -> 2 position	-	440	610	mA
		All switches in COM -> 1 position	-	90	120	
	USB Port	All switches in COM -> 2 position	-	10	20	
		All switches in COM -> 1 position	-	10	20	
Switching Time		-	-	25	-	ms
Life (per switch) ²		@ 100 mW (hot switching) ³	10	-	-	million switching cycles
		@ 1 W (hot switching) ³	-	3	-	
RF Power (cold switching) ⁴		-	-	-	10	W
RF Power (hot switching) ⁴		-	-	-	1	
RF VSWR		DC to 1 GHz	-	1.05	1.10	:1
		1 GHz to 8 GHz	-	1.20	1.30	
		8 GHz to 12 GHz	-	1.20	1.35	
		12 GHz to 18 GHz	-	1.25	1.40	
RF Insertion Loss (per switch)		DC to 1 GHz	-	0.10	0.15	dB
		1 GHz to 8 GHz	-	0.15	0.30	
		8 GHz to 12 GHz	-	0.25	0.40	
		12 GHz to 18 GHz	-	0.30	0.50	
RF Isolation (per switch)		DC to 1 GHz	85	100	-	dB
		1 GHz to 8 GHz	75	90	-	
		8 GHz to 12 GHz	70	80	-	
		12 GHz to 18 GHz	60	66	-	

² Capable of up to 100 million cycles with proper maintenance, contact Mini-Circuits³ Exceeding these limits will result in reduced life.⁴ Power handling is specified with RF applied to the COM port and output load connected to either 1 or 2 of the respective switch.

Minimum System Requirements

Interface	USB HID or HTTP Get/Post or Telnet protocols
Host operating system - USB Control	Windows 32/64 Bit operating system: Windows 98 [®] , Windows XP [®] , Windows Vista [®] , Windows 7 [®] , Windows 8 [®] Linux[®] support: 32/64 Bit operating system
Host operating system - Ethernet Control	Any Windows [®] , Mac [®] , or Linux [®] computer with a network port and Ethernet-TCP/IP (HTTP or Telnet protocols) support
Hardware	Pentium [®] II or better ⁵

⁵ Pentium[®] is a registered trademark of Intel Corporation

Connections


24V _{DC} IN	(2.1 mm center positive DC Socket)
RF Switch A (1, COM, 2)	(SMA female)
RF Switch B (1, COM, 2)	(SMA female)
USB	(USB type B receptacle)
Network (Ethernet/LAN)	(RJ45 socket)

Absolute Maximum Ratings

Operating Temperature	0°C to 40°C
Storage Temperature	-15°C to 45°C
DC Voltage max.	26V
RF power (at COM port of any switch)	10W
RF power (at 1 and 2 of any switch)	1W

Permanent damage may occur if any of these limits are exceeded.

Block Diagram




USB/Ethernet RF Switch Matrix


RC-2SPDT-A18

Outline Drawing (LM1849)

TOP VIEW




FRONT VIEW




BOTTOM VIEW

Shown with Rubber feet removed and Brackets installed.




REAR VIEW



BRACKET OPTION

ONE SET OF 2 EACH.



INSTRUCTION FOR MOUNTING BRACKETS:

TOOL REQUIRED:

PHILLIPS HEAD SCREW DRIVER
STEP 1: REMOVE RUBBER FEET FROM THE BOTTOM OF THE UNIT. DO NOT DISCARD THE FASTENERS.

STEP 2: MOUNT THE BRACKETS WITH THE FASTENERS REMOVED IN STEP 1, USING THE COUNTER-BORE HOLES IN THE BRACKET.

Outline Dimensions (inch mm)

A	B	C	D	E	F	G	H	J	K	WT. GRAMS
6.00	4.50	2.25	0.440	1.28	1.47	0.28	3.500	.375	6.75	875
152.4	114.3	57.2	11.18	32.5	37.3	7.1	88.9	9.52	171.4	

 **Mini-Circuits**®

www.minicircuits.com P.O. Box 35166, Brooklyn, NY 11235-0003 (718) 934-4500 sales@minicircuits.com

Page 5 of 10

Configuration A: 2 SPDT switches

- Power handling is specified with RF applied to the COM port and output load connected to either 1 or 2 of the respective switch.
- When connecting a coaxial semi flex cable, tighten connectors alternately using an 8in/lb torque wrench to insure proper contact at each end.

USB Control

Power Supply Indicator: **ON** **Disconnected** **Connected**

Ethernet-Config

Main Control

Model Name: **RC-2SPDT-A18**

Serial Number: (fw) **11305120002**

Address (1 to 255): **234** **Set**

Standard Switch Configurations:

- Use as SP3T Switch**
- Use as DPDT Switch**
- User Sequence**


COM > 1

RF Switch A
Mini-Circuits MSP2TA-18

COM > 1

RF Switch B
Mini-Circuits MSP2TA-18


Note: Switches A,B move independently.

Config. A

SPDT: Switch A, or B Logic
 IN \longleftrightarrow Out1 : 0
 IN \longleftrightarrow Out2 : 1
 Switches move independently.



Configuration B: DPDT switch

- Power handling is specified with RF applied to the COM port and output load connected to either 1 or 2 of the respective switch.
- When connecting a coaxial semi flex cable, tighten connectors alternately using an 8in/lb torque wrench to insure proper contact at each end.



Configuration C: SP3T switch

- Power handling is specified with RF applied to the COM port and output load connected to either 1 or 2 of the respective switch.
- When connecting a coaxial semi flex cable, tighten connectors alternately using an 8in/lb torque wrench to insure proper contact at each end.

**Config. C****SP3T:**


Switch A & B Logic

IN \longleftrightarrow Out1 : 0, \emptyset
 IN \longleftrightarrow Out2 : 1, 0
 IN \longleftrightarrow Out3 : 1, 1

Both switches move together as one.

User Switching Sequence - for setting any configuration or sequence needed

- Power handling is specified with RF applied to the COM port and output load connected to either 1 or 2 of the respective switch.
- When connecting a coaxial semi flex cable, tighten connectors alternately using an 8in/lb torque wrench to insure proper contact at each end.



- For instructions on using the GUI See the [user guide](#) on Mini-Circuits' website
- For programming instructions of the switch matrix see the [programming guide](#) and [AN-49-001](#) on Mini-Circuits' website

Ordering, Pricing & Availability Information see our web site

Model	Description
RC-2SPDT-A18	USB/Ethernet RF SPDT Switch Matrix

Included Accessories	Part No.	Description
	AC/DC-24-3W1	AC/DC 24V _{DC} Grounded Power Adaptor. Operating temperature: 0°C to +40°C, I _{Max} =2.5A
	CBL-3W1-XX	AC Power Cord (Select one power cord from below with each Switch Matrix box)
	RFSW-CD	Software CD
	USB-CBL-AB-3+	2.7 ft (0.8 m) USB Cable: USB type A(Male) to USB type B(Male)
	CBL-RJ45-MM-5+	5 ft (1.5 m) Ethernet cable: RJ45(Male) to RJ45(Male) Cat 5E cable

AC Power Cords ⁶	Part No.	Description
	CBL-3W1-US	Power Cord for United States
	CBL-3W1-EU	Power Cord for Europe
	CBL-3W1-UK	Power Cord for United Kingdom
	CBL-3W1-AU	Power Cord for Australia and China
	CBL-3W1-IL	Power Cord for Israel

⁶ Power cords for other countries are also available, if you need a power cord for a country not listed in the table please contact apps@minicircuits.com or check <http://www.minicircuits.com/contact/offices.html> for regional offices e-mail and phone numbers.

Optional Accessories	Description
USB-CBL-3+ (spare)	2.7 ft (0.8 m) USB Cable: USB type A(Male) to USB type B(Male)
USB-CBL-7+	6.8 ft (2.1 m) USB Cable: USB type A(Male) to USB type B(Male)
USB-CBL-11+	11 ft (3.4 m) USB Cable: USB type A(Male) to USB type B(Male)
CBL-RJ45-MM-5+ (spare)	5 ft (1.5 m) Ethernet cable: RJ45(Male) to RJ45(Male) Cat 5E cable
BKT-272-08+	Bracket (One set of 2 each)

Additional Notes

- A. Performance and quality attributes and conditions not expressly stated in this specification document are intended to be excluded and do not form a part of this specification document.
- B. Electrical specifications and performance data contained in this specification document are based on Mini-Circuit's applicable established test performance criteria and measurement instructions.
- C. The parts covered by this specification document are subject to Mini-Circuits standard limited warranty and terms and conditions (collectively, "Standard Terms"); Purchasers of this part are entitled to the rights and benefits contained therein. For a full statement of the Standard Terms and the exclusive rights and remedies thereunder, please visit Mini-Circuits' website at www.minicircuits.com/MCLStore/terms.jsp