

5300 Beethoven Street, Los Angeles, CA 90066 TEL: (310)306-5556 • FAX: (310)577-9887 WEB: www.ophirrf.com • E-MAIL: sales@ophirrf.com

ъ.

MODEL 5127R-900

20 - 1000 MHz 200 WATTS LINEAR POWER RF AMPLIFIER

Solid State Broadband High Power RF Amplifier

The 5127R-900 is a 200 Watt broadband amplifier that covers the 20 – 1000 MHz frequency range. This amplifier utilizes Class A/AB linear power devices that provide an excellent 3rd order intercept point, high gain, and a wide dynamic range.

Due to robust engineering and employment of the most advanced devices and components, this amplifier achieves high efficiency operation with proven reliability. Like all OPHIR_{RF} amplifiers, the 5127R-900 comes with an extended multiyear warranty.

	<u>Parameter</u>	Specification @ 25° C
<u>Electrical</u>		
1	Frequency Range	20 – 1000 MHz
2	Saturated Output Power	200 Watts typical
3	Power Output @ 1dB Comp.	120 Watts min
4	Small Signal Gain	+54 dB min
5	Gain Flatness	<u>+</u> 3.0 dB max
6	IP ₃	+57 dBm typical
7	Input VSWR	2:1 max
8	Harmonics	-20 dBc typical @ 120 Watts
9	Spurious Signals	< -60 dBc typical @ 120 Watts
10	Input/Output Impedance	50 Ohms nominal
11	AC Input Power	3000 Watts max
12	AC Input	200 – 240 VAC, single phase
13	RF Input	0 dBm max
14	RF Input Signal Format	CW/AM/FM/PM/Pulse
15	Class of Operation	AB
<u>Mechanical</u>		
16	Dimensions	19" x 8.75" x 20"
17	Weight	77 Lbs.
18	Connectors	Rear Panel, Type-N
19	Grounding	Chassis
20	Cooling	Internal Forced Air
<u>Environmental</u>		
21	Operating Temperature	0° C to +50° C
22	Operating Humidity	95% Non-condensing
23	Operating Altitude	Up to 10,000' Above Sea Level
24	Shock and Vibration	Normal Truck Transport Specifications subject to change without notice.

CIRCUIT PROTECTIONS

- ♦ Thermal Overload
- ♦ Over Current
- ◊ Over Voltage

FEATURES

- ♦ Customer Specific Front Panel
- ♦ Rear Panel Mounted DB9-Female for External RF Enable / Standby Control NOTE: Pin **5** is GND, Pin **1** is the Control Line.
 - IF Pin 1: OPEN RF Standby Condition (Nominal Gain 30dB min.)
 - IF Pin 1: GND RF Enabled (Amplifier in Normal Operation) (< 100mA to Activate)